

CB&S

Certified Balance & Scale

www.certify911.com
office@certify911.com
ph: 800-777-1198
ph: 815-895-5158

YSI MULTILAB 4010-2/3 FIRMWARE UPDATING

The following procedures are meant as an overview and supplement the manufacturer's instruction from the owner's manual.

Preliminary:

1. On the Multilab, press and hold the “Enter” button until “Storage & Config”
2. Select “System” and then “Service Information”. Note Software version “V _____”
3. Go to <https://www.yei.com/customer-support/software-firmware-downloads/software> and observe if your version matches the current version. If it doesn't, follow below procedures.

Firmware updating:

1. Download the firmware package
2. Find/Run/Install the package
3. Find and Open the installed program
4. Connect the USB patch cord from PC to the Multilab instrument
5. Turn Multilab on.
6. Install update by selecting “OK” and waiting for process to complete.

These procedures give an overview. Different PCs, operating systems, and Com port settings may cause you to run into problems. If you make changes and still can't succeed, call YSI tech support: 800-765-4974. The menu tree is 2,1,3 after the main number.

Contact us for supplies, equipment, and yearly certification options:

office@certify911.com
www.certify911.com